


SMART TOWER SCENT DIFFUSER

INSTRUCTION MANUAL



Please read the manual carefully and keep it properly before use

Scent Diffuser Introduction

Our Scent Diffuser utilizes the latest cold-air diffusion technology which turns any of our hotel-inspired fragrance oil into a dry nano-mist, allowing the scent to stay idle in the air for much longer while providing superior, long-lasting coverage. It uses no water or heat and preserves the therapeutic properties of our fragrance oils without altering their smell.


Uses advanced atomization technology which makes it residue free and safe for pets, children, artwork, and furniture. This model comes with an easy to use remote control and bluetooth capabilities.



What 's Included:

Scent diffuser, power adapter, bottle, atomization core, remote, instruction manual

Light Indicator:




Blue light: indicates that the device is powered on.

Green light: indicates that the device is working normally.

Red light: flashing red light indicates that the remote is communicating with the device.


Instructions To Use:



Rotate the upper part of the device in a counter-clockwise direction and then lift it apart from the bottom.



Next, turn the bottle counterclockwise to detach it from the diffuser head and pour in your favorite fragrance.




Re-insert the top of the diffuser into the bottom, ensuring a tight fit by twisting it clockwise.



Plug in the device and then using the remote press the "On" button to turn it on. Please follow the remote control instructions step by step to adjust the settings.

Remote Control:



Remote control code matching:

If the remote control is lost or needs to be replaced for other reasons, you can continue to use the device through "code matching": disconnect the power first, and then hold down the **ON** button while plugging in the power supply again, at the same time if the red indicator flashes, it indicates that the device and the remote control matching (that is, the code matching) is complete.

How To Use Remote Control:

ON- Press to turn on device

OFF- Press to turn device off

AROMA- Press the "AROMA" button while the device is turned on to reset the device to its factory settings.

+ - Pressing Density + button once will increase a mist level each time until the maximum.

- - Pressing Density - button once will decrease a mist level each time until the minimum.

The settings below determine how long the device will mist before turning off, and this cycle continues until the set time interval is completed:

- L1-** The diffuser will emit the scent for 16s, followed by a pause of 360s.
- L2-** The diffuser will emit the scent for 16s, followed by a pause of 300s.
- L3-** The diffuser will emit the scent for 16s, followed by a pause of 240s.
- L4-** The diffuser will emit the scent for 16s, followed by a pause of 180s.
- L5-** The diffuser will emit the scent for 16s, followed by a pause of 120s.
- L6-** The diffuser will emit the scent for 16s, followed by a pause of 60s.

Please note: in the default settings for the diffuser, it will emit scent for 16 seconds and then pause for 240 seconds. This cycle will continue until the diffuser is turned off.

Timer setting allows the diffuser to run continuously for a specified period of time and automatically turn off.

1h- 1 hour

4h- 4 hours

8h- 8 hours

Bluetooth Setting:

◇ Home

Mobile phone scan code to download and install "Scent Tech", start the APP, complete the beginner's guide, select Bluetooth mode to enter the home page, at this time the available devices column displays the available Bluetooth devices that have been plugged in within the Bluetooth range, click to select the available devices to enter the status page.

Tip: App permission configuration, including location services, Bluetooth connection, and sending notifications are allowed.

◇ Status page

- Status window: Displays the current working mode parameters and status, including time, day, Bluetooth connection status (gray when Bluetooth is not connected), etc.



- Operation status: the mobile phone can turn on/off the device operation with one button;
- Working Mode: Displays the currently running working mode
- Device Address: After the device is successfully configured with the network, the network location address is obtained.
- Click More in the top right corner: Rename device.

◇ Mode settings

Click the working mode bar to enter the mode setting, you can set 5 groups of working modes respectively, click any mode bar to customize the day, timing power on and off time period, gear setting, etc.

- Week settings: Customize the work days of the week.

- Time period number: Customize the time period that needs to be scented.

Note: It cannot be set across days (the end time cannot be less than the start time), if you need to set the work across 00:00, set the continuous time period at both ends respectively, for example, you need to set 23:00~02:00 work, respectively set to 23:00~23:59, 00:00~02:00 two groups.

- Working level setting: The spatial fragrance concentration can be adjusted (by controlling the frequency of fragrance spraying).

Technical Features

- Size: 85×85×285mm
- Weight : 0.9Kg
- Coverage: 200m³
- Oil bottle capacity: 120 ml
- Voltage: DC12V
- Power: 4W

Maintenance:

If the diffuser is not used for a long time, 95% industrial alcohol should be added into the oil bottle to clean the nozzle and other parts inside the diffuser. Tip: Maintain the diffuser with 95% industrial alcohol at least every 1-2 months.

Specific operation: add 95% industrial alcohol into the empty bottle, turn on the diffuser and run for 10-15 minutes after, then turn off the diffuser and pour the alcohol, then screw back the bottle to machine.

Replacing The Nozzle:



1. To change the nozzle, unplug the diffuser, remove the bottle of oil and carefully pull out the clear tube. Gently pull out the black nozzle by wiggling it gently using a pair of tweezers.



2. Replace it with a new nozzle and ensure the nozzle is pressed very firmly into the top of the diffuser. The tube can be reinserted into the nozzle.

Warranty

- 1.The Warranty is suitable for new machine but not reselled or second hand products.
- 2.Within 12 months after purchase date, Warranty is offered for all qualified machines. During warranty we will offer repair services and the free parts but not include essential oil.
- 3.The warranty card & purchase Invoice are needed if after-sales service is required. Please contact us within warranty if any problems.
- 4.The following is not suitable for warranty service:
 - ① Damage & problems caused by Accidents & Fire.
 - ② Not used properly and wrong operation.
 - ③ Repaired by the unprofessional and cause some parts damaged.
 - ④ Damaged during transportation.
 - ⑤ Without our warranty card.
 - ⑥ Without proper cleaning for a long time
 - ⑦ The machine work time out.
 - ⑧ Machines & Parts not from us.
 - ⑨ Machines not purchased from official sales channels.
 - ⑩ Send the machines back without permit from manufacturer.

Notice

1. Please carefully read the Instruction before installation, and keep the User manual to check if need at anytime
2. Please make sure the machine stays upright, no leaking and no down; or may damage the device and parts
3. Please do not open the machine by yourself, If problems, please contact us promptly.